



**CAUTION: PLEASE DO NOT BEND THE BELT REPEATEDLY**  
注意：請不要反覆彎曲皮帶

## HOW TO SET YOUR COMBINATION LOCK

如何重新設定密碼：

1. Lock preset at **0-0-0**, press the button (C) to open the lock.

1. 出廠密碼預設為**0-0-0**，按下按鈕(C)，即可開鎖。

2. Press and hold the button (A) and turn the dials (B) to your desired numbers.

2. 按壓按鈕(A)，將數字字輪(B)轉到你想要的數字。

3. Released the button (A). Now the lock will open at the desired number.

3. 鬆開按鈕(A)，鎖已經設定好為新的密碼。

4. Check to be sure the button moves freely at this combination.

Before turning the dials to lock the case, write down your code and put in a safe place.

Reminder: After setting the code, please press the button (C) to complete the setup.

4. 檢查以確保數字字輪在新密碼設定下可以開鎖/解鎖。

設定好新的密碼時，請牢記新密碼。